

Product Manual | Ball Marine Winch Handle (Pro)

Winch Compatibility and Correct Use

The Ball Marine winch handle is compatible with most major winch brands, however we recommend you check to ensure the product fits correction, locks and releases before using the handle.

The winch handle should be removed from winches when not being actively used to reduce the risk of injury.

The winch handle should not be used for stability or seating purposes.

Additional care should be taken when using electric winches. Before use, insert the winch handle, stand clear, press the power button and ensure the handle does not rotate with the winch.

Winch handles should only be used for their correct application – as a leverage device for compatible winches.

Store winch handle away from sharp objects and hard services to avoid scratching and damage.

Product Maintenance and Care Instructions



After use, we recommend rinsing the product with fresh running water and drying external parts well.

For a deeper clean (recommended only periodically) use a mild detergent and water solution. Rotate grip and grip knob, compress lock pin and trigger mechanism to distribute soap solution evenly. Flush and rinse well with fresh water and hand dry well.

Servicing and Warranty Claims

Please contact Ball Marine Limited for 'how to' information and service providers for maintaining and servicing your winch handle.

Warranty information is available via our website at www.ballmarine.com